

User Manual

4.2KVA/7.0KVA
INVERTER / CHARGER

Table Of Contents

ABOUT THIS MANUAL	3
Purpose	3
Target Group	3
SAFETY REGULATIONS	3
INTRODUCTION	4
Features	4
Basic System Architecture	4
Product Overview	5
INSTALLATION	6
Unpacking And Inspection	6
Preparation Before Installation	6
Installation	6
Battery Connection	7
Lead-Acid Battery Connection	7
Lithium Battery Connection	8
AC Input/Output Connection	11
PV Connection	12
Final Assembly	13
OPERATION	14
Power On/Off	14
Operation And Display	14
LED Indicator	14
Function Keys	14
LCD Display Icons	15
LCD Setting	16
Display Setting	22
Operating Mode Description	24
Fault Code	25
Warning code	26
BATTERY EQUALIZATION	27
SPECIFICATIONS	29
Table 1 Specification of LINE Mode	29
Table 2 Specification of Inverter Mode	30
Specification of Charging Mode	30
Table 5 General specifications	31
TROUBLE SHOOTING	32

ABOUT THIS MANUAL

Purpose

This manual introduces the assembly, installation, operation and troubleshooting of inverter. Please read this manual carefully before installation and operation.

Target Group

This manual is designed for professionals and end users. Operations that do not require any specific skills can also be handled by the end users themselves. Professionals must have the following skills:

- Understand how the inverter works and operates
- After training, someone knows that how to deal with crises and risks in the installation and use of electrical equipment and devices
- After training, someone knows that how to install and commission electrical equipment and fixtures
- Understand the applicable standards and directives
- Understand and abide by this manual and all safety knowledge

SAFETY REGULATIONS

Warning: This article contains important safety and operation instructions. Please read and save this manual for future reference.

1. Please choose the corresponding setting according to whether to use lead-acid battery or lithium battery. If it is not set properly, the system may not operate normally.
2. Before using the unit, please read all the instructions and cautionary on the unit and understand all battery models and relevant chapters in this manual.
3. Never short-circuit AC output and DC input. Never connect the mains when the DC input is short-circuited.
4. Never change a non-rechargeable battery.
5. Do not disassemble the unit. When maintenance or repair is needed, please send it to the professional technical service center. Incorrect reassembly may lead to electric shock or fire.
6. To reduce the risk of electric shock, disconnect all wiring before attempting any maintenance or cleaning. Turning off the device will not reduce this risk.
7. Be extra careful when using metal tools on or around the battery. Some potential risks, such as short circuit of batteries or other electronic components caused by sparks caused by falling tools, may lead to explosion.
8. In order to realize the optimal operation of this off grid solar inverter, please select the appropriate cable size according to the instruction. It is very important to operate the off grid solar inverter correctly.
9. When disconnecting AC or DC terminals, please strictly follow the installation procedure. For more details, please refer to "Installation" in this manual.
10. Grounding instruction this off grid solar inverter shall be connected to the permanent grounding wiring system. Be sure to comply with local requirements and regulations to install this inverter.
11. Provide a fuse that meets certain specifications for battery power supply as overcurrent protection.
12. **Warning!** Only professional service personnel can repair this equipment. If there are still errors after troubleshooting, please send this off line solar inverter back to the local dealer or service center for maintenance.

INTRODUCTION

This is a multifunctional off grid solar inverter, which integrates MPPT solar charging controller, high-frequency pure sine wave inverter and UPS function module, and is very suitable for off-grid backup power supply and spontaneous self-use system. The design of high-frequency transformer enables the machine to provide reliable power conversion in a small size. This inverter can also work in battery-free mode.

The whole system also needs other equipment to achieve complete operation, such as photovoltaic modules, generator or utility grid. According to your requirements, please consult your system integrator to obtain other possible system components. WiFi module is a plug-and-play monitoring device installed on the inverter. With this device, users can monitor the running status of solar system anytime and anywhere through mobile phones or websites.

Features

- Pure sine wave output inverter
- According to the requirements of load (household appliances/personal computers), the input voltage range of utility grid can be selected
- According to the battery requirements, the charging current can be set through LCD
- Solar energy and utility grid can power loads at the same time
- AC input is compatible with mains and generator
- Automatic restart function when mains power is restored
- RS485 port Used for communication with BMS
- Overload/ Over temperature/ short circuit protection
- The intelligent charging design of battery makes the battery more fully utilized
- Cold start function
- Intelligent fan speed adjustment, which adjusts the fan speed according to temperature, load and charging current
- Built-in MPPT, operating voltage range 55V~430V, open circuit voltage 450Voc
- WiFi remote monitoring (optional)

Basic System Architecture

The following illustration shows basic application for this inverter/charger. It also includes following devices to have a complete running system:

- Generator or mains electricity
- Solar module (optional)

Consult with your system integrator for other possible system architectures depending on your requirements. This inverter can power all kinds of appliances in home or office environment, including motor type appliances such as tube light, fan, refrigerator and a ir conditioner.





Figure 1 Hybrid Power System

Product Overview



1. LCD screen
2. Status indicator
3. Charging indicator
4. Fault indicator
5. Function keys
6. Power on/off
7. AC input
8. AC output
9. PV input
10. Battery input
11. RS232/RS485 communication port
12. Ground wire terminal

INSTALLATION

Unpacking And Inspection

Unpack the inverter and make sure there are no damaged objects in the package. You should have received the following items inside of package:

- Machine x 1
- User manual x 1

Preparation Before Installation

Before connecting all wirings, please take off bottom cover by removing two screws as shown below.

Installation

Please consider the following points before installing the equipment:

1. Do not install the inverter on flammable building materials;
2. Install on a solid surface;
3. Install this inverter at eye level in order to allow the LCD display to be read at all times;
4. Leave a gap of 20-50 cm for ventilation and heat dissipation of the equipment;
5. The equipment working environment temperature should be 0-55°C;
6. It is the best to install it vertically down against the wall, leaving a certain space with the ground.

1. SUITABLE FOR INSTALLATION ON CONCRETE OR OTHER NON-COMBUSTIBLE SURFACE ONLY

Tighten the screws and fix the installation. Machine fixing screws: M4 or M5 screws are recommended.

Battery Connection

Lead-Acid Battery Connection

WARNING: In order to operate safely and comply with laws and regulations, it is required to install an independent DC overcurrent protector or disconnect device between the battery and the inverter.

WARNING: All wiring must be performed by a qualified personnel.

WARNING: It's very important for system safety and efficient operation to use appropriate cable for battery connection. To reduce risk of injury, please use the proper recommended cable and as below.

Recommended battery cable specifications:

Model	Wire specification		Torque value
4.2KVA-24V	1 * 2 AWG	34mm ²	2-3 Nm
7KVA-48V	1 * 4 AWG	22mm ²	2-3 Nm


Note: The recommended charging current of lead-acid battery is 0.2C (C is battery capacity).

Please follow below steps to implement battery connection:

1. Connect the battery according to the recommended battery cable specifications.
2. Connect all battery packs as needed.
3. Insert the ring terminal of the battery cable into the battery connector of the inverter flatly, and ensure that the bolts are tightened with a torque of 2-3 Nm. Make sure that the polarities of the battery and inverter are connected correctly, and tighten the ring terminal with the battery terminal.

	WARNING: Shock Hazard Installation must be performed with care due to high battery voltage in series.
	CAUTION! Do not place anything between the flat part of the inverter terminal and the ring terminal, otherwise, it may cause short circuit or overheating.
	CAUTION! Do not apply antioxidant to the terminal before it is tightly connected.
	CAUTION! Before making the final DC connection or closing DC breaker/disconnector, be sure positive (+) must be connected to positive (+) and negative (-) must be connected to negative (-).

4. Connect all battery packs in the following table.



Lithium Battery Connection

If choosing lithium battery for the inverter, only lithium batteries that have been matched with BMS communication protocol are allowed.

1. Connect the battery according to the recommended battery cable specifications.
2. Insert the ring terminal of the battery cable into the battery connector of the inverter flatly, and ensure that the bolts are tightened with a torque of 2-3 Nm. Make sure that the polarities of the battery and inverter are connected correctly, and that the ring terminal is tightened with the battery terminal.

3. Connect one side of RJ45 cable to the BMS communication port of inverter.


4. Insert the other side of RJ45 cable into RS485 communication port on lithium battery.

Note: If you choose a lithium battery, please make sure to connect the battery and inverter with BMS communication cable, and select the battery type as "LIB" mode.

Communication And Setting Of Lithium Battery

1. Connect the RJ45 communication cable between inverter and battery. Please confirm that the lithium battery BMS port's PIN is correspond with the inverter BMS communication port. The inverter BMS port's PIN definition as below:

Pin number	Port definitions
1	TX
2	RX
3	VCC
4	VCC
5	RS485A
6	RS485B
7	GND
8	GND



Communication port pin definition

2. In order to communicate with the lithium battery BMS, you should press the "ENTER" button for a long time, and set the battery type as "LIB" in program 05. Then select the matching battery protocol in Program 10.

05	Battery type	AGM (default)
		05 <u>AGM</u>
		Flooded
		05 <u>FLd</u>
		User Defined
05	Lithium battery mode	05 <u>USE</u>
		05 <u>LIB</u>
		Lithium battery communication mode
		LIB 05 485

10	Lithium battery protocol	PYLON ID PYL
		PACE ID PRC

3. In "LIB" mode, press and hold the "ESC" button to view the information of the lithium battery, and the inverter display screen will enter the following screen (the initial interface shows the total battery voltage and remaining battery capacity). Press the "DOWN" button to display the following data in turn.

Battery voltage	The remaining battery capacity
Battery charging current	Battery discharge current
The rated capacity of the battery	Cycle charge and discharge times
BMS board temperature	MOS temperature
The maximum voltage of single battery cell	The minimum voltage of single battery cell
The maximum temperature of single battery	The minimum temperature of single battery

Battery Alarm Code

Alarm code	Alarm event	Icon flashing
21	Battery Cell Over Voltage	[21] ①
22	Battery Cell Under Voltage	[22] ①
23	Battery Pack Over Voltage	[23] ①
24	Battery Pack Under Voltage	[24] ①
25	Charging Over Current	[25] ①
26	Discharging Over Current	[26] ①
27	Charging Cell Over Temperature	[27] ①
28	Discharging Cell Over Temperature	[28] ①
29	Charging Cell Under Temperature	[29] ①
30	Discharging Cell Under Temperature	[30] ①
34	Battery capacity is too low	[34] ①
44	Battery Cell Voltage Imbalance	[44] ①
45	Battery Cell Temperature Imbalance	[45] ①
46	Internal Communication Alarm	[46] ①

Battery fault code

Fault code	Fault event	The icon is long and bright
21	Battery Cell Over Voltage	[21] [ERROR]
22	Battery Cell Under Voltage	[22] [ERROR]
23	Battery Pack Over Voltage	[23] [ERROR]
24	Battery Pack Under Voltage	[24] [ERROR]
25	Charging Over Current	[25] [ERROR]
26	Discharging Over Current	[26] [ERROR]
27	Charging Cell Over Temperature	[27] [ERROR]
28	Discharging Cell Over Temperature	[28] [ERROR]
29	Charging Cell Under Temperature	[29] [ERROR]
30	Discharging Cell Under Temperature	[30] [ERROR]
31	Ambient Over Temperature	[31] [ERROR]
32	Ambient Under Temperature	[32] [ERROR]
33	MOS Over Temperature	[33] [ERROR]
35	Battery Short Circuit	[35] [ERROR]
36	Charge Overvoltage	[36] [ERROR]
37	System Failure	[37] [ERROR]
39	Charging MOS Fault	[39] [ERROR]
40	Discharge MOS Fault	[40] [ERROR]
41	Temperature Sensor Fault	[41] [ERROR]
42	Battery Cell Fault	[42] [ERROR]
43	Sampling Communication Failure	[43] [ERROR]
61	Communication Failure	[61] [ERROR]

AC Input/Output Connection

CAUTION! Before connecting to AC input power source, please install a separate AC breaker between inverter and AC input power source. This will ensure the inverter can be securely disconnected during maintenance and fully protected from over current of AC input.

CAUTION! There are two terminal blocks with "IN" and "OUT" markings. Please do NOT mis-connect input and output connectors.

WARNING! All wiring must be performed by a qualified personnel.


WARNING! It's very important for system safety and efficient operation to use appropriate cable for AC input connection. To reduce risk of injury, please use the proper recommended cable size as below.

Suitable cable specifications for AC wires

Model	Wire Gauge	Torque Value
4.2KVA-24V	1 * 10 AWG	1.2-1.6 Nm
7KVA-48V	1 * 8 AWG	1.2-1.6 Nm

Please follow below steps to implement AC input/output connection:


1. Before making AC input/output connection, be sure to open DC protector or disconnect first.
2. Remove insulation sleeve 10mm for six conductors. And shorten phase L and neutral conductor N 3 mm.
3. Insert AC input wires according to polarities indicated on terminal block and tighten the terminal screws. Be sure to connect PE protective conductor (⊕) first.
 ⊕ → Ground (yellow-green)
 L → LINE (brown or black)
 N → Neutral (blue)



WARNING: Be sure that AC power source is disconnected before attempting to hardware it to the unit.

4. Then, insert the AC output conductor according to the polarity identification at the terminal, and tighten the screw.

L → LINE (brown or black)
N → Neutral (blue)



5. Make sure the wires are firmly connected.

CAUTION: Please ensure that all AC cables are connected correctly according to the corresponding polarity.

CAUTION: Appliances such as air conditioner are required at least 2~3 minutes to restart because it's required to have enough time to balance refrigerant gas inside of circuits. If a power shortage occurs and recovers in a short time, it will cause damage to your connected appliances. To prevent this kind of damage, please check manufacturer of air conditioner if it's equipped with time-delay function before installation. Otherwise, this inverter will trip overload fault and cut off output to protect your appliance but sometimes it still causes internal damage to the air conditioner.

PV Connection

CAUTION: Before connecting the PV module, please install separately a DC circuit breaker between the inverter and PV module.

WARNING! All wiring must be performed by a qualified personnel.

WARNING! It's very important for system safety and efficient operation to use appropriate cable for PV module connection. To reduce risk of injury, please use the proper recommended cable size as below.

Model	Wire Gauge	Torque Value
4.2KVA-24V	1 * 12 AWG	1.2-1.6 Nm
7KVA-48V	1 * 12 AWG	1.2-1.6 Nm

PV Module Selection:

When selecting proper PV modules, please be sure to consider below parameters:

1. Open circuit Voltage (Voc) of PV modules not exceeds max. PV array open circuit voltage of inverter.
2. Open circuit Voltage (Voc) of PV modules should be higher than min battery voltage.

Model	4.2KVA-24V	7KVA-48V
PV open circuit voltage	450Vdc	
MPPT operating voltage range	55Vdc~430Vdc	


Take 250Wp PV module as an example. After considering above two parameters, the recommended module configurations are listed as below table:

Solar panel parameters	Solar Input	Qty of panels	Total Input
Range (Min in serial: 6 pcs, max in serial: 11 pcs)			
-250Wp	6 pcs in serial	6	1500W
-Vmp: 30.1Vdc	8 pcs in serial	8	2000W
-Imp: 8.3A	11 pcs in serial	11	2750W
-Voc: 37.7Vdc	8 pieces in serial and 2 sets in parallel	16	4000W
-Isc: 8.4A	11 pieces in serial and 2 sets in parallel	22	5500W
-Cells: 60	8 pieces in serial and 3 sets in parallel	24	6000W

3. Equipment Assembly

Please follow below steps to implement PV module connection:

- 1) Remove insulation sleeve 10 mm for positive and negative conductors.
- 2) Check correct polarity of connection cable from PV modules and PV input connectors. Then, connect positive pole (+) of connection cable to positive pole (+) of PV input connector. Connect negative pole (-) of connection cable to negative pole (-) of PV input connector.
- 3) Make sure the wires are securely connected.



Final Assembly


After connecting all the wires, put the bottom cover back and screw the screws.

OPERATION

Power On/Off

After installing the machine correctly and connecting the battery correctly, just press the On/Off switch to turn on the machine.

Operation And Display



The operation and display panel is shown in the following figure, which is located on the front panel of the inverter. It includes four function keys and an LCD screen for indicating operation status and input/output power information.


LED Indicator

LED Indicator		Messages	
AC / INV	Green	Solid On	Output is powered by utility in Line mode.
		Flashing	Output is powered by battery or PV in battery mode.
CHG	Green	Solid On	Battery is fully charged.
		Flashing	Battery is charging.
FAULT	Red	Solid On	Fault occurs in the inverter.
		Flashing	Warning condition occurs in the inverter.

Function Keys

Function Key	Description
ESC	To exit setting mode
UP	To go to previous selection
DOWN	To go to next selection
ENTER	To confirm the selection in setting mode or enter setting mode

LCD Display Icons



Icon	Function description
Input Source Information	
AC	Indicates the AC input.
PV	Indicates the PV input
INPUT BATT	Indicate input voltage, input frequency, PV voltage, battery voltage and charger current.
Configuration Program and Fault Information	
88	Indicates the setting programs.
88	Flashing with warning code.
88	Lighting with fault code
Output Information	
OUTPUT LOAD	Indicate output voltage, output frequency, load percent, load in VA, load in Watt and discharging current.
Battery Information	
	Indicates battery level by 0-24%, 25-49%, 50-74% and 75-100% in battery mode and charging status in line mode.
In AC mode, it will present battery charging status.	
Status	Battery voltage
LCD Display	
Battery voltage	
4 bars will flash in turns.	
2 ~ 2.083V/cell	
Bottom bar will be on and the other three bars will flash in turns.	
2.083 ~ 2.167V/cell	
Bottom two bars will be on and the other two bars will flash in turns.	
> 2.167 V/cell	
Bottom three bars will be on and the top bar will flash.	
Floating mode. Batteries are fully charged.	
4 bars will be on.	
In battery mode, it will present battery capacity.	
Load Percentage	Battery Voltage
LCD Display	
Battery Voltage	
< 1.717V/cell	
1.717V/cell ~ 1.8V/cell	
Load > 50%	
1.717V/cell ~ 1.8V/cell	

50% > Load > 20%	1.8 ~ 1.883V/cell	
	> 1.883 V/cell	
	< 1.817V/cell	
	1.817V/cell ~ 1.9V/cell	
	1.9 ~ 1.983V/cell	
Load < 20%	> 1.983V/cell	
	< 1.867V/cell	
	1.867V/cell ~ 1.95V/cell	
	1.95 ~ 2.033V/cell	
	> 2.033 V/cell	

Load Information	
OVERLOAD	Indicates overload.
Indicates the load level by 0-24%, 25-50%, 50-74% and 75-100%.	
0~24%	25~50%
50%~75%	75%~100%
Mode Operation Information	
	Indicates unit connects to the mains.
	Indicates unit connects to the PV panel.
BYPASS	Indicates load is supplied by utility power.
	Indicates the utility charger circuit is working.
	Indicates the DC/AC Inverter circuit is working.
	Indicates unit alarm is disabled.

LCD Setting

After pressing and holding "ENTER" button for 3 seconds, the unit will enter setting mode. Press "UP" or "DOWN" button to select setting programs. And then, press "ENTER" button to confirm the selection or "ESC" button to exit.

Setting Programs:

Option	Describe	Optional Item	
00	Exit setting mode	Escape 00 <u>ESC</u>	
01	Output source priority: To configure load power source priority	SUB priority (default) 01 <u>SUB</u>	Solar energy gives priority to supplying power to the load. If solar energy can't effectively provide all connected loads, Utility will provide power to the loads at the same time.
		SBU priority 01 <u>SBU</u>	Solar energy gives priority to supplying power to the load. If solar energy cannot effectively provide all connected loads, the battery will supply power to the loads at the same time. Utility provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.
		10A 02 <u>10</u> A	20A 02 <u>20</u> A
		30A 02 <u>30</u> A	40A 02 <u>40</u> A
		50A 02 <u>50</u> A	60A (default) 02 <u>60</u> A
		70A 02 <u>70</u> A	80A 02 <u>80</u> A
		90A 02 <u>90</u> A	100A 02 <u>100</u> A
		110A 02 <u>110</u> A	
		Appliances (default) 03 <u>APL</u>	If selected, acceptable AC input voltage range will be within 90-280VAC.
		UPS 03 <u>UPS</u>	If selected, acceptable AC input voltage range will be within 170-280VAC.
03	Ac input voltage range	Saving mode disable(default) 04 <u>SdS</u>	If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected.
04	Power saving mode enable/disable	Saving mode enable 04 <u>SEN</u>	If enabled, the output of inverter will be off when connected load is pretty low

		AGM (default) 05 <u>AGM</u>	Flooded 05 <u>FLD</u>
05	Battery type	User-Defined 05 <u>USE</u>	LIB 05 <u>LIB</u>
		LIB-485 LIB 05 <u>485</u>	If USE or LIB is selected, battery charge voltage and low DC cut-off voltage can be set up in program 26, 27 and 29.
		Restart disable(default) 06 <u>LTd</u>	Restart enable 06 <u>LT-E</u>
06	Auto restart when overload occurs	Restart disable(default) 07 <u>LT-d</u>	Restart enable 07 <u>LT-E</u>
07	Auto restart when over temperature occurs	220V 08 <u>220</u> V	230V (default) 08 <u>230</u> V
08	Output voltage	240V 08 <u>240</u> V	
09	Output frequency	50Hz (default) 09 <u>50</u>	60Hz 09 <u>60</u>
10	Lithium battery protocol	PYLON (default) 10 <u>PYL</u>	PAGE 10 <u>PAC</u>
11	Maximum Utility charging current	10A 11 <u>10</u> A	20A 11 <u>20</u> A
		30A (default) 11 <u>30</u> A	40A 11 <u>40</u> A
		50A 11 <u>50</u> A	60A 11 <u>60</u> A
		70A 11 <u>70</u> A	80A 11 <u>80</u> A
		Available options in 24V models: 22V 12 <u>220</u> V	22.5V 12 <u>225</u> V
		23V (default) 12 <u>230</u> V	23.5V 12 <u>235</u> V
12	Setting voltage point back to utility source when selecting "SBU priority"	24V	24.5V

	12 <u>240</u> ^v	12 <u>245</u> ^v
	25V <u>250</u> ^v	25.5V <u>255</u> ^v
	Available options in 48V models:	
	44V <u>44</u> ^v	45V <u>45</u> ^v
	46V (default) <u>46</u> ^v	47V <u>47</u> ^v
	48V <u>48</u> ^v	49V <u>49</u> ^v
	50V <u>50</u> ^v	51V <u>51</u> ^v
	Available options in 24V models:	
	Battery full charged <u>13 FULL</u>	24V <u>13 240</u> ^v
	24.5V <u>13 245</u> ^v	25V <u>13 250</u> ^v
	25.5V <u>13 255</u> ^v	26V <u>13 260</u> ^v
	26.5V <u>13 265</u> ^v	27V (default) <u>13 270</u> ^v
	27.5V <u>13 275</u> ^v	28V <u>13 280</u> ^v
	28.5V <u>13 285</u> ^v	29V <u>13 290</u> ^v
	Available options in 48V models:	
	Battery full charge <u>13 FULL</u>	48V <u>13 480</u> ^v
	49V <u>13 490</u> ^v	50V <u>13 500</u> ^v
	51V <u>13 510</u> ^v	52V <u>13 520</u> ^v
	53V <u>13 530</u> ^v	54V (default) <u>13 540</u> ^v
	55V <u>13 550</u> ^v	56V <u>13 560</u> ^v
	57V <u>13 570</u> ^v	58V <u>13 580</u> ^v
13	Setting voltage point back to battery mode when selecting "SBU priority" in program 01	

	13 <u>570</u> ^v	13 <u>580</u> ^v
	If this inverter/charger is working in Line, Standby or Fault mode, charger source can be programmed as below:	
	Solar first <u>16 CS0</u>	Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available.
	Solar and Utility(default) <u>16 SNU</u>	Solar energy and utility will charge battery at the same time.
	Only Solar <u>16 OS0</u>	Solar energy will be the only charger source no matter utility is available or not.
	If this inverter/charger is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it's available and sufficient.	
18	Alarm on (default) <u>18 60N</u>	Alarm off <u>18 60F</u>
	Return to default display screen(default) <u>19 ESP</u>	If selected, no matter how users switch display screen, it will automatically return to default display screen (Input voltage /output voltage) after no button is pressed for 1 minute.
19	Stay at latest screen <u>19 LEP</u>	If selected, the display screen will stay at latest screen user finally switches.
20	Backlight on(default) <u>20 LON</u>	Backlight off <u>20 LOF</u>
22	Alarm on (default) <u>22 R0N</u>	Alarm off <u>22 R0F</u>
23	Overload bypass: When enabled, the unit will transfer to line mode if overload occurs in battery mode.	Bypass disable (default) <u>23 BYD</u>
25	Record fault code	Bypass enable <u>23 BYE</u>
	Record enable <u>25 FEN</u>	Record disable(default) <u>25 FDS</u>
	Default setting of 24V model: 28.2V	
	<u>CU 26 282</u> ^v	
	Default setting of 48V model: 56.4V	
	<u>CU 26 564</u> ^v	
26	Bulk charging voltage (C.V voltage)	
	If USE or LTB is selected in program 5, this program can be set up. Set voltage range, 24V model: from 24V to 29.2V;	

		48V Model: from 48.0V to 58.4V, and each press increases by 0.1V.
		Default setting of 24V model: 27.0V FLV 27 270 ^v
27	Floating charging voltage	Default setting of 48V model: 54.0V FLV 27 540 ^v If USE or LIB is selected in program 5, this program can be set up. Set voltage range, 24V model: from 24V to 29.2V; 48V Model: from 48.0V to 58.4V, and each press increases by 0.1V.
		Default setting of 24V model: 21.0V COV 29 210 ^v
		Default setting of 48V model: 42.0V COV 29 420 ^v
29	Low DC cut-off voltage	If USE or LIB is selected in program 5, this program can be set up. set voltage range, 24V model: from 20V to 24V; 48V models range from 40V to 48V. Increment of each click is 0.1V. Low DC cut-off voltage will be fixed to setting value no matter what percentage of load is connected.
33	Battery equalization	Battery equalization 33 EEN 33 EDS Battery equalization disable(default) If "Flooded" or "User-Defined" is selected in program 05, this program can be set up.
		Default setting of 24V model: 29.2V EV 34 292 ^v
		Default setting of 48V model: 58.4V EV 34 584 ^v
34	Battery equalization voltage	The setting range of 24V model is from 25.0V to 29.5V, and 48V model is from 50V to 59.0V. Increase by 0.1V per press.
35	Battery equalized time	60min (default) 35 60 Setting range is from 5 min to 900min. Increment of each click is 5min.
36	Battery equalized timeout	120min (default) 36 120 Setting range is from 5min to 900 min. Increment of each click is 5min.
37	Equalization interval	30 days (default) 37 30d Setting range is from 0 to 90 days. Increment of each click is 1 day
39	Equalization activated immediately	Enable 39 REN 39 RDS Disable(default) If equalization function is enabled in program 33, this program can be set up. If "Enable" is selected in this program, it's to activate battery equalization immediately and LCD mainpage will show "Eq". If "Disable" is selected, it will cancel equalization function until next activated equalization time arrives based on program 37 setting. At this time, "v" will not be shown in LCD main page.

Display Setting

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selectable information is switched as below order: input voltage, input frequency, PV voltage, MPPT charging current, MPPT charging power, battery voltage, output voltage, output frequency, load percentage, load in VA, load in Watt, DC discharging current, main CPU Version and second CPU Version.

Selectable information	LCD display
Input voltage/Output voltage (Default Display Screen)	<p>Input Voltage=230V, output voltage=230V</p>
Input frequency	<p>Input frequency=50Hz</p>
PV voltage	<p>PV voltage =260V</p>
MPPT Charging current	<p>MPPT charging power=500W</p>
Charging current	<p>AC and PV charging current=50A</p>









	<p>PV charging current=50A</p>
	<p>AC charging current=50A</p>
Battery voltage/ Output voltage	<p>Battery voltage=25.5V, Output voltage=230V</p>
Output frequency	<p>Output frequency=50Hz</p>
Load percentage	<p>Load percentage=70%</p>
Load in VA	<p>When connected load is lower than 1kVA, load in VA will present xxxVA like below chart.</p>

When load is larger than 1kVA, load in VA will present x.xkVA like below chart.



Load in Watt	<p>When load is lower than 1kW, load in W will present xxxW like below chart.</p> <p>When load is larger than 1kW, load in W will present x.xkW like below chart.</p>
Battery voltage/ DC discharging current	<p>Battery voltage=25.5V, discharging current=1A</p>
Main CPU version checking	<p>Main CPU version checking</p>
















Operating Mode Description

Operation mode	Description	LCD display
----------------	-------------	-------------



Standby mode / Power saving mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power saving mode: If enabled, the output of inverter will be off when connected load is pretty low or not detected.	No output is supplied by the unit but it still can charge batteries.	
		
		
Line Mode	The unit will provide output power from the mains. It will also charge the battery at line mode.	
		
		
Battery Mode	The unit will provide output power from battery and PV power.	
		

Fault Code

Fault Code	Fault Event	Icon on
01	Fan is locked when the inverter is turned off.	
02	Over temperature	

03	Battery voltage is too high	
04	Battery voltage is too low	
05	Output short circuit or over temperature.	
06	Output voltage is too high	
07	Exceeding overload time	
08	BUS voltage is too high	
09	BUS soft start failed.	
13	PV voltage is too high	
51	Over current and surge	
52	BUS voltage is too low	
53	Inverter soft start failed.	
55	Over DC voltage in AC output	
56	Battery is disconnected	
57	Current sensor failed.	
58	Output voltage is too low	

Warning code

Warning Code	Warning Event	Automatic Alarm	Icon Flashing
01	Fan is locked when inverter is on.	Beep three times every second	
03	Battery overcharge	Beep once every second	

04	Battery low voltage	Beep once every second	[04]▲
07	Overload	Beep once every 0.5 second	[07]▲
10	Output power is derating	Beep twice every 3 seconds	[10]▲
15	PV energy is weak	No Beep	[15]▲
EQ	Battery equalization	No Beep	[EQ]▲
bp	Battery is not connected.	No Beep	[bp]▲

BATTERY EQUALIZATION

Equalization function is added into charge controller. It reverses the buildup of negative chemical effects like stratification, a condition where acid concentration is greater at the bottom of the battery than at the top. Equalization also helps to remove sulfate crystals that might have built up on the plates. If left unchecked, this condition, called sulfation, will reduce the overall capacity of the battery. Therefore, it's recommended to equalize battery periodically.


● How to Apply Equalization Function

You must enable battery equalization function in monitoring LCD setting program 33 first. Then, you may apply this function in device by either one of following methods:

1. Setting equalization interval in program 37.
2. Active equalization immediately in program 39.


● When to Equalize

In float stage, when the setting equalization interval (battery equalization cycle) is arrived, or equalization is active immediately, the controller will start to enter Equalize stage.




● Equalize charging time and time out

In equalize stage, the controller will supply power to charge battery as much as possible until battery voltage rises to battery equalization voltage. Then, constant voltage regulation is applied to maintain battery voltage at the battery equalization voltage. The battery will remain in the Equalize stage until setting battery equalized time is arrived.




However, in Equalize stage, when battery equalized time is expired and battery voltage doesn't rise to battery equalization voltage point, the charge controller will extend the battery equalized time until battery voltage achieves battery equalization voltage. If battery voltage is still lower than battery equalization voltage when battery equalized time out setting is over, the charge controller will stop equalization and return to float stage.



SPECIFICATIONS

Table 1 Specification of LINE Mode

INVERTER MODEL	4.2KVA-24V	4.2KVA-48V	7KVA-48V
Input Voltage Waveform	Sinusoidal (utility or generator)		
Nominal Input Voltage	230Vac		
Low Loss Voltage	170Vac±7V (UPS) 90Vac±7V (Appliances)		
Low Loss Return Voltage	180Vac±7V (UPS); 100Vac±7V (Appliances)		
High Loss Voltage	280Vac±7V		
High Loss Return Voltage	270Vac±7V		
Max AC Input Voltage	300Vac		
Nominal Input Frequency	50Hz / 60Hz (Auto detection)		
Low Loss Frequency	40±1Hz		
Low Loss Return Frequency	42±1Hz		
High Loss Frequency	65±1Hz		
High Loss Return Frequency	63±1Hz		
Output Short Circuit Protection	Battery mode: Electronic Circuits		
Efficiency (Line Mode)	>95% (Rated R load, battery full charged)		
Transfer Time	10ms typical(UPS); 20m stpyical(Appliances)		
Output power derating: When AC input voltage drops to 95V or 170V depending on models, the output power will be derated.			




Table 2 Specification of Inverter Mode

INVERTER MODEL	4.2KVA-24V	4.2KVA-48V	7KVA-48V
Rated Output Power	3800W		
Output Voltage Waveform	Pure Sine Wave		
Output Voltage Regulation	230Vac±5%		
Output Frequency	60Hz or 50Hz		
Peak Efficiency	94%		
Overload Protection	5s@≥150% load;10s@110%~150% load		
Surge Capacity	2* rated power for 5 seconds		
Nominal DC Input Voltage	24Vdc	48Vdc	
Cold Start Voltage	23.0Vdc	46.0Vdc	
Low DC Warning Voltage			
@ Load < 20%	22.0Vdc	44.0Vdc	
@ 20% ≤ Load < 50%	21.4Vdc	42.8Vdc	
@ Load ≥ 50%	20.2Vdc	40.4Vdc	
Low DC Warning Return Voltage			
@ Load < 20%	23.0Vdc	46.0Vdc	
@ 20% ≤ Load < 50%	22.4Vdc	44.8Vdc	
@ Load ≥ 50%	21.2Vdc	42.4Vdc	
Low DC Cut-off Voltage			
@ Load < 20%	21.0Vdc	42.0Vdc	
@ 20% ≤ Load < 50%	20.4Vdc	40.8Vdc	
@ Load ≥ 50%	19.2Vdc	38.4Vdc	
High DC Recovery Voltage	29Vdc	58Vdc	
High DC Cut-off Voltage	31Vdc	62Vdc	
No Load Power Consumption	<25W	<50W	
Saving Mode Power Consumption	<10W	<15W	

Specification of Charging Mode

Utility Charging Mode			
INVERTER MODEL	4.2KVA-24V	4.2KVA-48V	7KVA-48V
Charging Current(UPS)	80A	60A	80A
@Nominal Input Voltage			

TROUBLE SHOOTING

Problem	LCD/Buzzer	Explanation / Possible cause	What to do
Unit shuts down automatically during startup process.	LCD and buzzer will be active for 3 seconds and then complete off.	Battery voltage is too low	1. Re-charge battery. 2. Replace battery.
No response after power on.	No indication.	1. The battery voltage is far too low. 2. Battery polarity is connected reversed.	1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery.
Mains exist but the unit works in battery mode.	Input voltage is displayed as 0 on the LCD	Input protector is tripped	Check if AC breaker is tripped and AC wiring is connected well.
	The power-on icon of LCD flashes, and the status indicator icon flashes.	Insufficient quality of AC power. (Shore or Generator)	1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage range setting is correct. (UPS→Appliance)
	Fault code 07	Overload error: The inverter is overload 110% and time is up.	Reduce the connected load by switching off some equipment.
	Fault code 05	Output short circuited.	Check if wiring is connected well and remove abnormal load.
	Fault code 02	Internal temperature of inverter component are over heated.	Check whether the air flow of the unit is blocked or whether the ambient temperature is too high.
Buzzer beeps continuously and the status indicator icon is always on.	Fault code 03	Battery is over-charged. The battery voltage is too high.	Return to repair center.
	Fault code 01	Fan fault	Check if spec and quantity of batteries are meet requirements.
	Fault code 06/58	Output abnormal	1. Replace the fan load. 2. Return to repair center
	Fault code 08/09/53/57	Internal components failed.	Return to repair center.
	Fault code 51	Over current or surge.	Restart the unit, if the error happens again, please return to repair center.
	Fault code 52	Bus voltage is too low.	
	Fault code 55	Output voltage is unbalanced.	

Bulk Charging Voltage	Flooded Battery	29.2	58.4
	AGM / Gel Battery	28.2	56.4
Floating Charging Voltage	27Vdc	54Vdc	
Charging Algorithm	3-Step		

Charging Curve

The graph illustrates the 3-step charging process for a battery. The primary y-axis represents 'Battery Voltage, per cell' in Volts, with markers at 2.00V, 2.25V, and 2.50V. The x-axis represents 'Time' in minutes, with markers at 10, 40, and 50. The charging curve starts at 2.00V, rises to 2.25V at 10 minutes, remains constant until 40 minutes, then rises to 2.50V and remains constant until 50 minutes. The graph is divided into three regions: 'Bulk (Constant Current)' from 0 to 10 minutes, 'Absorption (Constant Voltage)' from 10 to 40 minutes, and 'Float (Constant Voltage)' from 40 to 50 minutes. A secondary y-axis on the right shows 'Charging Current, %' with markers at 100% and 50%.

INVERTER MODEL	4.2KVA-24V	4.2KVA-48V	7KVA-48V
Rated Power	6000W		
Rated Solar Voltage	300V		
PV Array MPPT Voltage Range	55V-430V		
Max. PV Array Open Circuit Voltage	450V		
Max Charging Current	110A	80A	110A

Table 5 General specifications

INVERTER MODEL	4.2KVA-24V	4.2KVA-48V	7KVA-48V
Operating Temperature Range	0°C to 55°C		
Storage temperature	-15°C~60°C		
Dimension (D*W*H), mm	423*300*120		
Net Weight, kg	7.3	7.4	8